




VMM5220 FW:5.05.219 Upgrade tool as below:

AtUsbHid.dll	2006/11/17 10:50	应用程序扩展	68 KB
cmd_leaf_running_status_check	2018/3/23 9:49	文本文档	6 KB
FLK_MST_834_0226.fullrom	2019/2/26 14:28	FULLROM 文件	512 KB
VmmDPTool	2018/7/13 9:32	应用程序	5,036 KB
VmmUpdater	2018/7/13 9:32	应用程序	5,036 KB
VmmUSBTool	2018/7/13 9:32	应用程序	4,696 KB

1. Setup: Windows Host/Laptop + UP-DP2XDP + Monitor

2. Open the file "VmmDPTool", click FLASH → LOAD to FLAH → choose "Firmware"



Check the firmware version

